1 Your Phone


Earphone jack
Earpiece
Screen
Camera
Speaker
Volume
control
Microphone
Charging/Data
interface

2 Keys & Functions



1 Send key
2 Left soft key
3 Speaker key
4 Confirm key
5 Navigation key
6 Camera key
7 Right soft key
8 End key
9 Del key
10 Enter key
11 Input method/Lock key
12 Sym key
13 Space key
14 Caps key
15 Fn/Vibrate key

3 Getting Started

Installing the Battery



Installing the microSD Card



4 Charging the Battery

Before charging the battery, make sure that the battery has been properly inserted into your mobile phone.



1. Connect the charger to a power outlet.
2. Connect the charger to the charger connector of the phone. The phone begins charging. When the battery icon changes to , it indicates that your phone is fully charged.
3. When the phone is fully charged, disconnect the charger from the phone and then from the power outlet.

5 Making a Call

1. In standby mode, enter the phone number.
- To make an international call, enter a plus sign (+). Then enter the international longdistance code, country code or region code, area code, and phone number in sequence.
- To call an extension, enter the phone number, press **P key** to insert P or press **Fn/Vibrate key** and **T key** to insert T, and then enter the extension number.

2. Press **Send key** to dial the number.
3. Press **End key** to end the call.

6 Entering Text

Entering Words

Press the key labeled with the desired letter to enter a word.

- Press **Fn/Vibrate key** then letter key for alternate character on key.
- Press **Space key** to enter a space.
- Press **Sym key** to display the symbol list. Then you can select and enter a symbol.
- Press **Caps key** to switch between uppercase and lowercase letters.
- Press **Input method/Lock key** to change input method.

Entering Numbers and symbols

- In “123” input mode, press the key labeled with the numbers or symbols.
- In “abc” and “es” input mode, press **Fn/Vibrate key** and then the key labeled with the numbers or symbols.

7 Multimedia

Taking a Photo

1. In standby mode, select **Menu** > **Tools** > **Camera** to launch the camera.
2. Focus the camera on the scene. Press **Confirm key** to take a photo.
3. Your photo is automatically saved to the album of the default storage that you select.

Playing Music

1. To start the music player, select **Menu** > **Music player**.
2. Select **Options** > **Media** library to select songs to be played.

8 Bluetooth

You can exchange data between your Bluetooth phone and other Bluetooth devices. If you want to exchange data between your phone and another device, that device must support Bluetooth and the Bluetooth function must be enabled.

1. Select **Menu** > **Settings** > **Connectivity** > **Bluetooth** > **Bluetooth** > **On** to enable the Bluetooth function.
2. Select **Search for Device** to search a Bluetooth device. When a Bluetooth device is found for the first time, authentication is required.
3. If the Bluetooth(BT) accessory that is to be connected requires a password, the message "Enter password:" will appear. Enter the BT accessory password, normally it is 0000 (four zeros). After the same password is entered (sometimes requires entry on both devices) the Bluetooth connection is set up.
4. Launch the application that contains the file to be sent. Select the file you want to send. Select **Options** and select **Send** > **Via Bluetooth**.

9 Important Safety Information

This section contains important information pertaining to the operating instructions of your device. It also contains information about how to use the device safely. Read this information carefully before using your device.

Electronic Device

Power off your device if using the device is prohibited. Do not use the device when using the device causes danger or interference with electronic devices.

Medical Device

- Follow rules and regulations set forth by hospitals and health care facilities. Do not use your device when using the device is prohibited.
- Pacemaker manufacturers recommend that a minimum distance of 15 cm be maintained between a device and a pacemaker to prevent potential interference with the pacemaker. If you are using a pacemaker, use the device on the opposite side of the pacemaker and do not carry the device in your front pocket.
- Some wireless devices may affect the performance of hearing aids. For any such problems, consult your service

provider.

• To ensure that the Hearing Aid Compatibility rating for your device is maintained, secondary transmitters such as Bluetooth and Wi-Fi components must be disabled during a call.

Potentially Explosive Atmosphere

Power off your device in any area with a potentially explosive atmosphere, and comply with all signs and instructions. Areas that may have potentially explosive atmospheres include the areas where you would normally be advised to turn off your vehicle engine. Triggering of sparks in such areas could cause an explosion or a fire, resulting in bodily injuries or even deaths. Do not power on your device at refueling points such as service stations. Comply with restrictions on the use of radio equipment in fuel depots, storage, and distribution areas, and chemical plants. In addition, adhere to restrictions in areas where blasting operations are in progress. Before using the device, watch out for areas that have potentially explosive atmospheres that are often, but not always, clearly marked. Such locations include areas below the deck on boats, chemical transfer or storage facilities, and areas where the air contains chemicals or particles such as grain, dust, or metal powders. Ask the manufacturers of vehicles using liquefi ed petroleum gas (such as propane or butane) whether this device can be safely used in their vicinity.

Traffic Security

Observe local laws and regulations while using the device. In addition, if using the device while driving a vehicle, comply with the following guidelines:

• Concentrate on driving. Your fi rst responsibility is to drive safely.

• Do not talk on the device while driving. Use hands-free accessories.

• When you have to make or answer a call, park the vehicle at the road side before using your device.

• RF signals may affect electronic systems of motor vehicles. For more information, consult the vehicle manufacturer.

• In a motor vehicle, do not place the device over the air bag or in the air bag deployment area. Otherwise, the device may hurt you owing to the strong force when the air bag infl ates.

• Do not use your device while fl ying in an aircraft. Power off your device before boarding an aircraft. Using wireless devices in an aircraft may cause danger to the operation of the aircraft and disrupt the wireless telephone network. It may also be considered illegal.

Operating Environment

• Do not use or charge the device in dusty, damp, and dirty places or places with magnetic fi elds. Otherwise, it may result in a malfunction of the circuit.

• The device complies with the RF specifi cations when the device is used near your ear or at a distance of 1.5 cm from your body. Ensure that the device accessories such as a device case and a device holster are not composed of metal components. Keep your device 1.5 cm away from your body to meet the requirement earlier mentioned.

• On a stormy day with thunder, do not use your device when it is being charged, to prevent any danger caused by lightning.

• When you are on a call, do not touch the antenna. Touching the antenna affects the call quality and results in increase in power consumption. As a result, the talk time and the standby time are reduced.

• While using the device, observe the local laws and regulations, and respect others' privacy and legal rights.

• Keep the ambient temperature between 0°C and 40°C while the device is being charged. Keep the ambient temperature between 0°C to 40°C for using the device powered by a battery.

Prevention of Hearing Damage

Using a headset at high volume can damage your hearing. To reduce the risk of damage to hearing, lower the headset volume to a safe and comfortable level.

Safety of Children

Comply with all precautions with regard to children's safety. Letting the child play with your device or its

accessories, which may include parts that can be detached from the device, may be dangerous, as it may present a choking hazard. Ensure that small children are kept away from the device and accessories.

Accessories

Use the accessories delivered only by the manufacturer. Using accessories of other manufacturers or vendors with this device model may invalidate any approval or warranty applicable to the device, result in the non-operation of the device, and cause danger.

Battery and Charger

- Unplug the charger from the electrical plug and the device when not in use.
- The battery can be charged and discharged hundreds of times before it eventually wears out. When the standby time and the talk time are shorter than the normal time, replace the battery.
- Use the AC power supply defi ned in the specifi cations of the charger. An improper power voltage may cause a fire or a malfunction of the charger.
- Do not connect two poles of the battery with conductors, such as metal materials, keys, or jewelries. Otherwise, the battery may be short-circuited and may cause injuries and burns on your body.
- If battery electrolyte leaks out, ensure that the electrolyte does not touch your skin and eyes. When the electrolyte

touches your skin or splashes into your eyes, wash your eyes with clean water immediately and consult a doctor.

• If there is a case of battery deformation, color change, or abnormal heating while you charge or store the battery, remove the battery immediately and stop using it. Otherwise, it may lead to battery leakage, overheating, explosion, or fire.

• If the power cable is damaged (for example, the cord is exposed or broken), or the plug loosens, stop using the cable at once. Otherwise, it may lead to an electric shock, a short circuit of the charger, or a fire.

• Do not dispose of batteries in fire as they may explode. Batteries may also explode if damaged.

• Do not modify or remanufacture, attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, expose to fire, explosion or other hazard.

• Avoid dropping the device or battery. If the device or battery is dropped, especially on a hard surface, and the user suspects damage, take it to a qualifi ed service center for inspection.

• Improper battery use may result in a fire, explosion or other hazard.

• Promptly dispose of used batteries in accordance with local regulations.

• The device should only be connected to products that bear the USB-IF logo or have completed the USB-IF compliance program.

• Only use the battery with a charging system that has been

qualifi ed with the system per this standard, IEEEStd-1725-2006. Use of an unqualifi ed battery or charger may present a risk of fi re, explosion, leakage, or other hazard.

• Replace the battery only with another battery that has been qualifi ed with the system per this standard, IEEEStd-1725-2006. Use of an unqualifi ed battery may present a risk of fi re, explosion, leakage or other hazard.

Cleaning and Maintenance

• The device, battery, and charger are not water-resistant. Keep them dry. Protect the device, battery, and charger from water or vapor. Do not touch the device or the charger with a wet hand. Otherwise, it may lead to a short circuit, a malfunction of the device, and an electric shock to the user.

• Do not place your device, battery, and charger in places where they can get damaged because of collision. Otherwise, it may lead to battery leakage, device malfunction, overheating, fi re, or explosion.

• Do not place magnetic storage media such as magnetic cards and fl oppy disks near the device. Radiation from the device may erase the information stored on them.

• Do not leave your device, battery, and charger in a place with an extreme high or low temperature. Otherwise, they may not function properly and may lead to a fire or an explosion. When the temperature is lower than 0°C, performance of the battery is affected.

• Do not place sharp metal objects such as pins near the

earpiece. The earpiece may attract these objects and hurt you when you are using the device.

• Before you clean or maintain the device, power off the device and disconnect it from the charger.

• Do not use any chemical detergent, powder, or other chemical agents (such as alcohol and benzene) to clean the device and the charger. Otherwise, parts of the device may be damaged or a fi re can be caused. You can clean the device and the charger with a piece of damp and soft antistatic cloth.

• Do not dismantle the device or accessories. Otherwise, the warranty on the device and accessories is invalid and the manufacturer is not liable to pay for the damage.

• If the device screen is broken by colliding with hard objects, do not touch or try to remove the broken part. In this case, stop using the device immediately, and then contact an authorized service center in time.

Emergency Call

You can use your device for emergency calls in the service area. The connection, however, cannot be guaranteed in all conditions. You should not rely solely on the device for essential communications.

Certifi cation Information (SAR)

This device meets guidelines for exposure to radio waves. Your device is a low-power radio transmitter and receiver. As recommended by international guidelines, the device is designed not to exceed the limits for exposure to radio

waves. These guidelines were developed by the independent scientifi c organization International Commission on Non-Ionizing Radiation Protection (ICNIRP) and include safety measures designed to ensure safety for all users, regardless of age and health. The Specifi c Absorption Rate (SAR) is the unit of measurement for the amount of radio frequency energy absorbed by the body when using a device. The SAR value is determined at the highest certifi ed power level in laboratory conditions, but the actual SAR level of the device when being operated can be well below the value. This is because the device is designed to use the minimum power required to reach the network.

The SAR limit adopted by USA and Canada is 1.6 watts/kilogram (W/kg) averaged over one gram of tissue. The highest SAR value reported to the FCC and IC for this device type when tested for use at the ear is 1.130 W/kg, and when properly worn on the body is 0.992 W/kg.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However,there is no guarantee that interference will not

occur in a particular installation.If this equipment does cause harmful interference to radio or television reception,which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

--Reorient or relocate the receiving antenna.

--Increase the separation between the equipment and receiver.

--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifi cations made to this device not expressly approved by Huawei Technologies Co., Ltd. may void the FCC authorization to operate this device.

Hearing Aid Compatibility (HAC) regulations for Mobile phones

In 2003, the FCC adopted rules to make digital wireless telephones compatible with hearing aids and cochlear implants. Although analog wireless phones do not usually cause interference with hearing aids or cochlear implants,

digital wireless phones sometimes do because of electromagnetic energy emitted by the phone's antenna, backlight, or other components.

Your phone is compliant with FCC HAC regulations (ANSI C63.19).

While some wireless phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise, and phones also vary in the amount of interference they generate. The wireless telephone industry has developed a rating system for wireless phones, to assist hearing device users find phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their box or a label located on the box. The ratings are not guarantees. Results will vary depending on the user's hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs. M-Ratings: Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. M4 is the better/higher of the two ratings.

T-Ratings: Phones rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device's telecoil ("T Switch" or "Telephone Switch") than unrated phones. T4 is the better/higher of the two ratings. (Note

that not all hearing devices have telecoils in them.) Hearing devices may also be measured. Your phone meets the M4/T4 level rating. Hearing devices may also be rated. Your hearing device manufacturer or hearing health professional may help you fi nd this rating.

For more information about the FCC Hearing Aid Compatibility please go to http://www.fcc.gov/cgb/dro.

Futurewei Technologies, Inc. Limited Warranty

Futurewei Technologies, Inc. (“Huawei”) represents and warrants to the original purchaser (“Purchaser”) that Huawei’s phones and accessories (“Product”) are free from material defects, including improper or inferior workmanship, materials, and design, during the designated warranty period, and subject to the following terms and conditions, when used normally and in accordance with all operating instructions:

1. Warranty Period: Coverage under this warranty is limited to the following time periods:

   a)Phone: a period of 12 months from the date of purchase.

   b)Battery and Charger: a period of 12 months from the date of purchase.

   c)Other accessories (If included in the box set): a period of 3 months from the date of purchase.

2. This limited warranty only applies to products manufactured by or for Huawei and that can be identified by the “Huawei” trademark, trade name, or logo affixed to them. The limited warranty does not apply to any non-Huawei products or software.

3. The Warranty extends only to Purchasers who purchased the Product in the United States of America and is not assignable or transferable to any subsequent purchaser/customer.

4. During the limited warranty period, Huawei will repair or replace at Huawei's sole option, any parts of the Product that are defective or malfunction during normal usage. Huawei reserves the right to use new or refurbished replacement parts in repair of the Product.

5. This limited warranty covers only the costs of parts and labor. Other related costs such as shipping and delivery costs may be born by purchaser at Huawei's option.

6. At Huawei's request, Purchaser must prove the date of the original purchase of the Product by a dated bill of sale or dated itemized receipt.

7. This warranty does not cover damage resulting from:

a)Abuse, accident, misuse, improper storage, exposure to liquid, moisture, or dampness;

b)External causes such as from collision, fire, flooding, sand, dirt, windstorm, lightning, or earthquake;

c)Exposure to extreme weather conditions, Acts of God, theft, blown fuse, or improper use of any electrical source;

d)Computer or internet viruses, bugs, worms, Trojan Horses, cancelbots;

e)Use with non-Huawei products or products not recommended for use with Huawei products;

f)normal wear and tear of the equipment;

g)Usage of equipment other than its normal and customary manner;

h)Improper testing, operation, maintenance, installation,

or any alteration or modification of Product;

i)Consumable parts, such as batteries, unless damage has occurred due to a defect in Huawei materials and workmanship;

j)Service performed by anyone who is not a Huawei representative or an authorized Huawei service provider;

k)Other acts which are not the fault of Huawei, including damage caused by shipping;

l)Cosmetic damages, including but not limited to dents or scratches in decorative, structural, or non-operative parts resulting from normal customer use;

m)Spillage of food or liquid, corrosion, rust or incorrect voltage; and

n)The defective function of the cellular system or inadequate signal reception by the external antenna, or viruses or other software problems introduced into the Product.

8. Huawei does not warrant that the operation of this product will be uninterrupted or error-free.

9. This warranty will also be null and void in any of the following events:

a)The serial number or warranty seal on the equipment has been altered, defaced or removed;

b)Any term contained in this warranty has been altered or modified in any way without prior written consent of Huawei;

c)Huawei has not been notified by Purchaser of the

alleged defect or malfunction of the Product during the applicable warranty period.

10. If Product is returned to Huawei after the expiration of the warranty period, Huawei's normal service policies shall apply and Purchaser will be charged accordingly.

a)Huawei assumes no obligation or liability beyond that which is expressly provided for in this limited warranty.

b)All warranty information, pricing, product features and specifications are subject to change.

11. This limited warranty provides Purchaser's sole and exclusive remedy to be provided by Huawei. The agents, employees, distributors, and dealers of Huawei products are not authorized to make modifications to this limited warranty, or make additional warranties binding on Huawei.

LIMIT OF LIABILITY

12. HUAWEI'S LIMIT OF LIABILITY UNDER THIS LIMITED WARRANTY SHALL BE THE ACTUAL CASH VALUE OF THE PRODUCT AT THE TIME PURCHASER RETURNS THE PRODUCT FOR REPAIR, AS DETERMINED BY THE PRICE PAID BY THE PURCHASER FOR THE PRODUCT LESS A REASONABLE AMOUNT OF USAGE. HUAWEI SHALL NOT BE LIABLE FOR ANY OTHER LOSSES OR DAMAGES SUCH AS SPECIAL, INCIDENTAL, CONSEQUENTIAL, OR PUNITIVE DAMAGES (INCLUDING BUT NOT LIMITED TO LOSS OF ANTICIPATED BENEFITS OR PROFITS, LOSS OF SAVINGS OR REVENUE, LOSS OF DATA, LOSS OF USE OF THE PRODUCT OR ANY ASSOCIATED EQUIPMENT, COST

OF CAPITAL, COST OF ANY SUBSTITUTE EQUIPMENT OR FACILITIES, DOWNTIME, ANY COSTS OF RECOVERING, REPROGRAMMING, OR REPRODUCING ANY PROGRAM OR DATA, ANY FAILURE TO MAINTAIN THE CONFIDENTIALITY OF DATA STORED ON THE PRODUCT, THE CLAIMS OF ANY THIRD PARTIES, INCLUDING SUBSEQUENT PURCHASERS, AND INJURY TO PROPERTY, RESULTING FROM THE PURCHASE OR USE OF THE PRODUCT OR ARISING FROM BREACH OF THIS WARRANTY, BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY, OR ANY OTHER LEGAL OR EQUITABLE THEORY, EVEN IF HUAWEI KNEW OF THE LIKELIHOOD OF SUCH DAMAGES). HUAWEI SHALL NOT BE LIABLE FOR DELAY IN RENDERING SERVICE UNDER THE LIMITED WARRANTY, OR LOSS OF USE DURING THE PERIOD THAT THE PRODUCT IS BEING REPAIRED.

DISCLAIMER OF WARRANTY

13. HUAWEI'S LIABILITY UNDER EITHER THE IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THE FOREGOING LIMITED WRITTEN WARRANTY. OTHERWISE, THE FOREGOING LIMITED WARRANTY IS PURCHASER'S SOLE AND EXCLUSIVE REMEDY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED.

14. Some states do not allow exclusion or limitation of incidental, consequential, or punitive damages, or permit limitations on the length of implied warranties, so certain of these warranty limitations may not apply to Purchaser.

This limited warranty gives Purchaser specific legal rights; Purchaser may also have other rights which vary from state to state. If any term of this limited warranty is held to be illegal or unenforceable, the legality or enforceability of the remaining terms shall not be affected or impaired.

15. This limited warranty allocates risk of Product failure between Purchaser and Huawei, and Huawei's Product pricing reflects this allocation of risk and the limitations of liability contained in this limited warranty.

Contact Huawei

WEB SITE: HTTP://WWW.HUAWEIDEVICE.COM

EMAIL: SUPPORTUSA@HUAWEI.COM

* This contact information may change without notice. Please contact your authorized Huawei retailer for updated contact information.

HUAWEI

All the pictures in this guide are for your reference only. The actual appearance and display depend on the mobile phone you purchase.

© 2011 Cricket Communications, Inc. The Cricket K is a registered trademark of Cricket Communications, Inc.

© Huawei Technologies Co., Ltd. 2011. All rights reserved.

V100R001C1T_01 96720290